



Cordless Circular Saw

TP-CS 18/136-C Li BL - Solo

Item No.: 4331240

Ident No.: 21014

Bar Code: 4006825683868

The Einhell Professional Cordless Circular Saw TP-CS 18/136-C Li BL - Solo is compact yet powerful. It is powered by an Einhell brushless motor, delivering greater power and longer runtime. A 10-year warranty applies to the motor after online registration. The Ø 136 mm HW/TCT saw blade achieves a cutting depth of up to 51 mm (90°) and can be changed quickly using the spindle lock. Angle and depth settings can be adjusted without tools. Features such as the cutting line indicator, parallel guide, LED light, aluminium saw table and extraction adapter ensure precision and cleanliness. Soft start, motor brake and soft-grip surfaces enhance safety. Compatible with the Einhell guide rail system. Supplied without battery.

POWER CHANGE

Features & Benefits

- Member of the Power X-Change family, requires 1x 18 V battery
- Brushless motor for more power and longer runtime
- Brushless 10-year motor warranty upon registration
- Compact and powerful
- Easy, tool-free adjustment (cutting depth, bevel angle)
- Visible cutting line indicator for guided sawing
- Parallel guide for precise cuts
- Compatible with Einhell guide rails
- High-quality aluminium saw table
- Softgrip surfaces for safe and comfortable working
- Soft start to protect the motor and the user
- LED light for illuminating the work area
- Vacuum adapter for a clean workspace
- Easy blade change thanks to spindle lock
- Double-sided safety switch for left- and right-handed users
- Includes 1x HW/TCT saw blade Ø 136 mm
- Supplied without battery and charger (available separately)

Technical Data

- No-load speed 4000 min^-1 Ø136 x Ø20 mm - Saw Blade - Number of saw teeth 16 Pieces - Cutting depth at 90° 51 mm - Cutting depth at 45° 35 mm

Logistic Data

- Product weight 2.26 kg - Gross weight single packaging 3.62 kg

- Dimensions single packaging 422 x 185 x 253 mm

- Pieces per export carton 4 Pieces - Gross weight export carton 16 ka

- Dimensions export carton 746 x 432 x 268 mm - Container quantity (20"/40"/40"HC) 1248 | 2496 | 3120











COMPACT & LIGHTWEIGHT

TOOLLESS











Available as special accessories



Guide Rail Alu 2x1000mm Circular Saw Accessory Item No.: 4502118 Bar Code: 4006825632675 Einhell Accessory



TCT SAWBL.M-THIN 136x20 16T-

Circular Saw Accessory Item No.: 4502077

Bar Code: 4006825686982



5,2 Ah Power X-Change Plus Battery Item No.: 4511437

Bar Code: 4006825616606

Einhell Accessory

3,0 Ah Power X-Change Plus

Battery Item No.: 4511501 Bar Code: 4006825644197 Einhell Accessory



PXC 18V 3,0Ah Battery Item No.: 4511341 Bar Code: 4006825590593 **Einhell Accessory**



2,0 Ah Power X-Change Battery

Item No.: 4511395 Bar Code: 4006825610369 **Einhell Accessory**



4,0 Ah Power X-Change Battery Item No.: 4511396 Bar Code: 4006825610376 **Einhell Accessory**



4-6 Ah Multi-Ah Power X-Change

Battery

Item No.: 4511502 Bar Code: 4006825644210





PXC 18V 2,5Ah Battery Item No.: 4511516 Bar Code: 4006825650518 Einhell Accessory



Power X-Fastcharger 4A Charger Item No.: 4512103 Bar Code: 4006825650228 Einhell Accessory



Power X-Twincharger 3A Charger Item No.: 4512069 Bar Code: 4006825629729

Einhell Accessory



18V 2,0Ah PXC Starter Kit PXC-Starter-Kit Item No.: 4512040 Bar Code: 4006825613681 Einhell Accessory



18V 4,0Ah PXC Starter Kit C1 PXC-Starter-Kit Item No.: 4512042 Bar Code: 4006825613704 Einhell Accessory



E-Case L with wheels System Carrying Case Item No.: 4540014 Bar Code: 4006825660562 Einhell Accessory



E-Case M System Carrying Case Item No.: 4540021 Bar Code: 4006825667721 Einhell Accessory

Battery-Running-Times

One Battery for All	sawing ¹	
<u> </u>	(null)	
1.5 Ah	21	
2.0 Ah	28	
2.5 Ah	35	
3.0 Ah	42	
4.0 Ah	56	
5.2 Ah	73	
6.0 Ah	84	
8.0 Ah	112	

For best performance select a battery with at least 2.5 Ah

Test setup:

1) softwood